

## **2.8 Definitions - H**

**Host Load:** The Load that is electrically interconnected within the defined electrical boundary of a BTM:NG Resource that is routinely served by, and assigned to, the Generator of a BTM:NG Resource. Station Power will be included in the calculation of the BTM:NG Resource's Host Load if it is self-supplied by the Generator of the BTM:NG Resource, and it is not separately metered pursuant to Section 5.12.6.1.1 and ISO Procedures.

**HTP Scheduled Line:** A transmission facility that interconnects the NYCA to the PJM Interconnection, L.L.C. Control Area at the West 49<sup>th</sup> Street Substation, New York, New York and terminates in Ridgefield, New Jersey.